


# *Japanparts*<sup>®</sup>



## **CAMSHAFT BEARINGS BRONZINE ALBERO A CAMME**



**SH1070B**

**5-11610-602**



**SH1158A**

**11802-87380**



DAIHATSU ROCKY Hard Top (F7, F8) 2.8 D  
DAIHATSU ROCKY Soft Top (F7, F8) 2.8 D  
DAIHATSU TAFT 2.5 D 4x4 (F50, F55)  
DAIHATSU TAFT 2.8 D 4x4 (F60, F65)  
DAIHATSU WILDCAT/ROCKY (F70) 2.8 D  
DAIHATSU WILDCAT/ROCKY (F70) 2.8 TD

**SH1161A**

**11802-54010**



TOYOTA CRESSIDA Station Wagon (X6K, MX62) 2.2 D  
TOYOTA CRESSIDA Tre volumi (\_X6\_) 2.2 D (LX60)  
TOYOTA HIACE I Furgonato (RH1\_, LH3\_, RH3\_, RH2\_, LH2\_, L 2.2 D (LH20-30)  
TOYOTA HIACE II Furgonato (LH5\_, YH7\_, LH7\_, LH6\_, YH6\_, 2.2 D

**SH1166B**

**5-11611-010**



ISUZU MIDI Autobus (94000, 98000) 2.0 TD (98000)  
ISUZU MIDI Autobus (94000, 98000) 2.2 D (98000)  
ISUZU MIDI Autobus (94000, 98000) 2.2 D 4WD (94000)  
ISUZU MIDI Furgonato (98000N) 2.0 TD  
ISUZU MIDI Furgonato (98000N) 2.2 D

**SH1195B**

**13002-06J01**



NISSAN PATROL GR I (Y60, GR) 4.2 Cat.

**SH1401B**

**11802-56011**



TOYOTA LAND CRUISER (\_J4\_) 3.0 D (BJ40\_V, BJ43\_)  
TOYOTA LAND CRUISER (\_J4\_) 3.4 D (BJ42\_V, BJ45\_V, BJ46\_)  
TOYOTA LAND CRUISER (\_J6\_) 3.4 Diesel (BJ60\_V)  
TOYOTA LAND CRUISER Pick-up (\_J4\_) 3.4 D (BJ45\_P)

**SH1417B**


**11802-56020**



TOYOTA DYNA Autobus (\_U3\_, \_U2\_) 3.4 D  
TOYOTA DYNA Pianale piatto/Telaio 3.4 D  
TOYOTA LAND CRUISER (PZJ7\_, KZJ7\_, HZJ7\_, BJ7\_, LJ7\_, RJ7 3.4 D (BJ70\_V, BJ73\_)  
TOYOTA LAND CRUISER (PZJ7\_, KZJ7\_, HZJ7\_, BJ7\_, LJ7\_, RJ7 3.4 TD (BJ71\_V)

**SH1431A**

**11802-54020**



TOYOTA DYNA 150 Pianale piatto/Telaio (LY\_) 3.0 D  
TOYOTA DYNA Pianale piatto/Telaio (KD\_, LY\_, TRY2\_, KDY2\_ 3.0 D4d  
TOYOTA HIACE IV Autobus (LH1\_) 2.4 TD (LXH12\_, LXH22\_)  
TOYOTA HIACE IV Autobus (LH1\_) 2.4 TD 4WD (H18/28)

**SH1436B**

**11801-17010**



TOYOTA LAND CRUISER (PZJ7\_, KZJ7\_, HZJ7\_, BJ7\_, LJ7\_, RJ7 4.2 TD (HZJ7\_V)  
TOYOTA LAND CRUISER 80 (\_J8\_) 4.2 D (HZJ80\_)  
TOYOTA LAND CRUISER 80 (\_J8\_) 4.2 TD (HDJ80)

**SH1605B**

**5-11610-002**



ISUZU CAMPO (KB) 2.2 D (KBD27)  
ISUZU CAMPO (KB) 2.2 D 4WD (KBD42, KBD47)  
ISUZU TROOPER (UBS) 2.2 D 4x4  
ISUZU TROOPER Fuoristrada aperto (UBS) 2.2 D (UBS52)  
ISUZU TROOPER Fuoristrada aperto (UBS) 2.2 TD (UBS52)  
OPEL CAMPO (TF\_) 2.2 D (TFR52)

**SH1622B**

**8-94168-556**



ISUZU CAMPO (KB) 2.5 D (TFR54)  
ISUZU CAMPO (KB) 2.5 D 4WD (KBD47)  
ISUZU NPR 55 2.8 TD (4JB1)  
ISUZU TROOPER (UB) 3.1 TD  
ISUZU TROOPER (UBS) 2.8 TD (UBS55)  
ISUZU TROOPER Fuoristrada aperto (UB) 3.1 TD  
OPEL CAMPO (TF\_) 2.5 D (TFR54)